

# STEALTH CAM

## STC-I840IR User's Manual



[www.stealthcam.net](http://www.stealthcam.net)

STC-I840IR

**For Customer Service or Warranty Information Call Toll Free**

**877-269-8490**

Stealth Cam, LLC

P.O. Box 539504

Grand Prairie, TX 75053-9504

[www.stealthcam.net](http://www.stealthcam.net)

## **Stealth Cam One Year Limited Warranty**

Your Stealth Cam scouting camera is covered by a One Year Limited Warranty on parts and labor from the date of original purchase, and purchases must be made through an authorized dealer. The warranty covers defects in workmanship and materials. The warranty does not apply to units, which have been damaged or abused intentionally or unintentionally. A purchase from individuals or unauthorized internet sites such as eBay voids the warranty.

Tampering with or altering the unit will void the warranty. Any unauthorized service will void warranty. Original sales receipt must be produced for any warranty service and a Return Authorization (RA) number must be obtained from customer service at 877-269-8490 prior to returning product.

[www.stealthcam.net](http://www.stealthcam.net)

Toll Free 877-269-8490

## STC-I840IR

### **Introduction**

Thank you for purchasing the Stealth Cam STC-I840IR digital video scout camera. Your Stealth Cam is designed to provide many years of service. The STC-I840IR is an infrared based camera with an industry leading Infrared emitter range of up to 40 feet. Special Burst Mode technology allows multiple exposures of up to 9 sequential still pictures or a programmable video segment between 10 to 180 seconds, when the PIR sensor is triggered.

Your STC-I840IR infrared camera provides superb color day time pictures or AVI video clips. When the infrared LED emitter is activated during low lighting conditions, it will provide you with black and white still pictures or AVI video clips.

## STC-I840IR

### **Contents**


- STC-I840IR Digital Video Scouting Camera
- User Manual
- USB cable
- Tree Mounting Strap

# Table of Contents

Warranty	2
Introduction	3
Camera Kit Contents	4
Table of Contents	5
Overview	6-8
Battery Power Options	9-10
Built-in Memory & SD Card Installation	11-13
Description of Features	14-16
Programming Your Scout Camera	17-23
Using your Camera	24-29
Manual Shooting Mode	30-31
Viewing Images and Deleting Images	32-36
Formatting memory	37
Using External Power Source	38
Technical Specifications	39
Camera Features	40-41
General Information	42-43
Moon Phase Chart	44


STC-I840IR

## Camera Overview - Front Cover Panel




STC-I840IR

## Camera Overview - Inside Control Panel



STC-I840IR

## Camera Overview - Inside Side Panel



## **Battery Power Options**

The Stealth Cam STC-I840IR is designed to operate using two different battery power options. The camera must be in the OFF position when installing or removing batteries. Use of batteries other than those specified in this section may damage the camera and void your warranty.

### **Using “C” Cell Batteries**

The internal battery compartment accepts 8 “C” cell batteries. Pull up on the bottom clip of the battery cover to open. Use fresh, high quality alkaline batteries. Install batteries in the correct polarity (+/-) referring to the illustration inside the battery compartment. Secure battery cover.

**Precaution:** When replacing batteries, replace all the batteries within 10 minutes. Otherwise, this will result in the loss of date / time setting

### **12V Lead Acid Battery (Recommended for extended field life)**

To avoid replacing batteries when out in the field, the STC-I840IR is equipped with an external power jack designed to accept a barrel plug cable that attaches to an optional lead acid battery (Stealth Cam STC-

## STC-I840IR

12VBB). Complete 12V Lead Acid battery kits offer significantly more usage than standard alkaline batteries. They are available at your Stealth Cam dealer, or call toll free (877) 269-8490. Only Stealth Cam external battery accessories are recommended.

## STC-I840IR

### **Built-in Memory & SD Memory Card Installation**

Your STC-I840IR camera is equipped with 32MB of built in flash memory. The camera is also equipped with an expandable media card slot capable of accepting up to a 2GB SD card (sold separately). With no memory card inserted into the slot, the camera will use the built in flash memory to store images. If an SD card is inserted into the slot then the camera will bypass the built in memory and utilize the SD card memory. The front counter display will show the number of images of either the built in flash memory or the inserted SD memory card after you turn on the camera.

## **Inserting the SD Memory Card**

***Make sure the camera is in the OFF position when you insert or remove a memory card.***

- Insert SD memory card into the card slot completely, and in the correct direction as shown on the inside of the housing.
  - To remove the SD memory card, push in the card and pull out the card gently.
- ❖ ***Brand new SD cards are ready for use. If you are using an SD card that was previously used in another camera, or other device, make sure to format the card prior to use in this camera.***
- ❖ **To ensure proper SD card formatting, insert it into the card slot and follow the steps page 37 to format the memory card.**

**Image & Video Capacity**

<b>SD card</b>	<b>High</b>	<b>Low</b>	<b>Base</b>	<b>AVI (seconds)</b>
32MB	23	36	58	38
64MB	47	72	117	76
128MB	94	144	233	152
256MB	187	289	467	304
512MB	374	578	934	608
1GB*	731	1,128	1,823	1,188
2GB*	1,462	2,257	3,647	2,375

\*Subject to card compatibility under different brands.

NOTE: Picture / Image Capacity Chart provides approximate number of images or AVI video based on resolution and image quality settings as well as the size of memory card used. These figures may vary depending on the amount of detail in the image.

## Description of Features

Below are illustrations and descriptions of the icons you will see on the internal LCD screen as you enter specific modes for programming.

### • Auto Mode:

- **Still images** – Captures from 1~9 pictures per PIR triggering
- **AVI video clip** – Captures video segments from 10 ~ 180 seconds per PIR triggering



- **Manual Mode:** Use as a point and shoot still image camera or video camera.

### • Image Resolution:

- **8.0M: 3,264 x 2,448** High image resolution
- **5.0M: 2,592 x 1,944** Low image resolution
- **3.0M: 2,048 x 1,536** Base image resolution






## STC-I840IR

- **VGA: 640 x 480** Default video resolution

- **Image Quality:**

- One star = Low Quality ★
- Two stars = Normal Quality ★★
- Three stars = High Quality ★★★

- **Battery Status:**

- **Full:** Batteries are full. 
- **Half:** Batteries are half depleted. 
- **Low:** Batteries are low. Front low battery LED indicator will flash. 

- ***When the camera has detected low batteries, (lower than 8.0 +/-0.5Volts for 1.5V C alkaline batteries; 10.0+/-0.5Volts for External 12V Lead Acid Battery) the camera unit will automatically power off within 30 seconds. Replace with new batteries as camera functions may not work properly.***

- **Date, Time, Moon Phase, & Temperature:** Information

## STC-I840IR

are shown on all your images and all video clips. (using Windows Media Player, Real Player, or Quick Time).

- **Time Out:** To program the amount of time in minutes (1~60) that the camera will sleep between PIR triggering.

## Programming your camera

Slide the power switch to TEST position. You will hear two short consecutive beeps followed by a third beep. Now you are ready to program your camera. Press the MENU button once to start your programming sequence.

### For Manual Capture Mode

To capture still image or video clip using the manual shutter button.

The Camera icon or Video icon will flash:  




Press Left/Right button to select between manual **Still Image Mode** or manual **AVI Video Mode**. Press the OK button to confirm your setting and then press Menu button to exit the programming mode. To continue manual capture mode, see page 30 for operating instructions.

For Auto capturing mode, press Menu again to begin your program setting sequence. You will see either your camera icon or video icon flashing.

## STC-I840IR

### **Resolution**

Press the down button twice. The Resolution icon will flash.


Press Left/Right button to select either high resolution 8.0M  , low resolution 5.0M  , or base resolution 3.0M 

Press OK to confirm the setting and the icon will stop flashing.

Press the Up button to change the previous setting, or the Down button to program the Quality setting.

**NOTE:** If you press **Menu** before pressing the OK button, you will exit the programming mode without saving your resolution setting.

### **Quality**

The Quality icon will flash: 

Press Left/Right button to select between:

Fine – Normal – Low

One star = Low quality 

Two stars = Normal quality 

Three Stars = Fine quality 

Press OK to confirm setting, the icon will stop flashing.

## STC-I840IR

Press the Up button to modify the previous setting or the Down button to program the TV out setting.

**NOTE:** If you press **Menu** before pressing the OK button, you will exit the programming mode without saving your quality setting.

### **TV (NTSC or PAL)**

The NTSC icon will be flashing. The factory default setting is NTSC for North America usage. If you don't need any changes, press Down button and skip to Date/Time setting.

Or Press Right button once to choose PAL setting.

Press O.K. to confirm setting, the icon will stop flashing. Press Menu to exit or press the Up button to modify previous setting or the Down button to enter Date/Time setting.

### **Date / Time Setting**

Date  
Time

**(The camera uses the 24 hour military time format only.)**

The Date/Time icon will flash.

Press OK to enter the setting mode.

**Set date and time.**

## STC-I840IR

The month digit will be flashing on the LCD screen.

Month - Day - Year  $\leftrightarrow$  Hour - Minute - Second

1. Press Up/Down button to select the appropriate month.
2. Press Right button to enter the date setting.
3. Press Up/Down button to select the appropriate date.
4. Press Right direction button to enter the year setting.
5. Press Up/Down button to select the appropriate year.
6. Press Right button to enter the time setting.
7. Press Up/Down button to select the appropriate hour in military time.
8. Press Right button to enter minute setting.
9. Press Up/Down button to select the appropriate minutes.
10. Press Right direction button to enter the seconds setting.
11. Press Up/Down button to select the appropriate second.

At the end of the time setting, press OK to confirm and exit the setting menu.

## **Stealth Cam Settings – Burst Mode Technology**

Stealth Cam digital cameras put you ahead of the game allowing you to set and Capture sequences by *programming 1-9 pictures per triggering, or 10 -180 seconds of video.*

### ***To Program Still Image Burst Mode:***

Slide the power switch from Off to Test position.

You will hear 2 consecutive short beeps follow by a 3<sup>rd</sup> beep. Press Menu button once and you will see the camera icon flashing. Press OK to confirm this option. Now press the DOWN button six times to scroll through all of the icon settings. You will now see the burst mode digit flashing.

Press Right button to select from 1 to 9 photos taken in sequence when the camera is triggered.

Press OK to confirm your Burst Mode photo setting.

Press the Down button to select the **Time Out** interval in minutes (1-60 min).

Press the Right button to increase the time interval by one minute increment or press the Left button to decrease the time interval by one minute increment.

## STC-I840IR

Press OK to confirm.

### ***To Program AVI clip Mode:***

Slide the power switch from Off to Test position.

You will hear 2 consecutive short beeps follow by a 3<sup>rd</sup> beep. Press Menu button once, then press the Right Button once. You will see the Movie icon flashing. Press O.K. to confirm this option.

Now press the Down button six times to scroll through all of the icon settings. You will now see the AVI length setting digits flashing.

Press Right button to select from 10 seconds to 180 seconds of video clip each time the camera is triggered.

Press OK to confirm your AVI length setting.

Press the Down button to select the **Time Out** interval in minutes (1-60 min).

Press the Right button to increase the time interval by one minute increment or press the Left button to decrease the time interval by one minute increment.

Press OK to confirm.

STC-I840IR

**Once all settings have been completed, press the MENU button to return to Camera Status Screen.**

## Using Your Camera

Once all program settings have been completed, your Stealth Cam is ready for field use. To begin, slide the power toggle switch from Test setting mode to the On position.

- ❖ ***Please note that when you power off the camera, the front LCD counter will remain on. This is normal.***


## Getting Started With Your Camera

### Mounting Your Camera

It is recommended to mount the camera 4~5 feet off the ground with the camera pointed at a slight downward angle. Avoid mounting the camera facing East or West as the rising and setting of the sun may produce false triggers and overexposed images. Clear branches and other debris away from the front of the camera so as not to block the camera lens or PIR sensor.

STC-I840IR


## Mounting the Camera with Supplied Strap



- Insert the strap through the strap slots on the rear housing.
  - Wrap the strap around the mounting surface. Secure the strap and tighten the buckle in order to secure the camera.
- ❖ ***In order to provide proper weather resistance, make sure that both door latches are securely locked in place.***

STC-I840IR

## PIR Cover Area Diagram



## Adjust the PIR Coverage Distance

- Your Stealth Cam offers a variable PIR detection distance.
- The PIR dial has Near to Far coverage.
- NEAR is approximately 15 ft; FAR is approximately 30 ft.
- Select the desired coverage distance.

## Testing the Camera Coverage Area

- After mounting the camera, open front housing and slide the power toggle switch to TEST.
- Close the front housing.
- Walk around in the front of the camera to see if you have mounted the camera in the proper position. A green indicator light on the front will blink when you have intruded the coverage area.
- Adjust the camera position as needed, and repeat testing until the desired coverage area is achieved.
- When you have completed testing the coverage area, open the front housing and slide the power toggle switch from TEST to ON position. This will exit the test mode. The camera will then enter one minute count down mode. The front green LED indicator will blink giving you one minute to leave the coverage area. Then the camera will enter PIR detection mode.

## Using the Camera in PIR Detection Mode

- Mount the camera to a tree or other sturdy object using either the supplied mounting strap. (Please refer to the mounting suggestions section in this manual)
- Open the front housing and slide the Toggle switch from OFF to TEST position. You will hear two short consecutive beeps followed by a third beep.
- Move the switch from Test to ON position to activate your PIR mode.
- The camera's green LED light will begin blinking and enter count down mode. This is your indication to leave the coverage area within one minute.
- After one minute, the camera will take between 1~9 pictures, or AVI video clip based on your program settings. The camera will then time out between 1~60 minutes also based on your selection.
- ❖ ***The time between motion detection and the camera taking pictures may vary due to lighting and environment conditions, program settings and battery power level.***

STC-I840IR

- ❖ *The IR emitter will only activate in low light conditions.*
- ❖ *AVI video operation is functional during day and night*

## **Manual Shooting Mode**

### **Using Manual Shoot Option in Still image mode**

- Slide the power toggle switch to TEST position. You will hear two short consecutive beeps followed by a third beep.
- Press the MENU button once. The Camera icon will flash.
- For still image capturing, press OK to select this option and press Menu to exit to status screen.
- Camera icon will stop flashing on the LCD screen to indicate still image mode.
- Point and hold the camera steady in the direction to capture an image, and press the SHUTTER button once. Wait for the one short beep follow by two consecutive beeps. This indicates the image has been captured, and the LCD counter will update the number of images in memory.

## Using Manual Shoot Option in AVI Mode

- Slide the power toggle switch to TEST position. You will hear two short consecutive beeps followed by a third beep.
- Press the MENU button. The Camera icon will flash.
- Press RIGHT button to select manual Video Capture Mode. Video icon will display on the LCD screen to indicate AVI mode.
- Press OK to confirm setting, and the icon will stop flashing.
- Press MENU to exit settings.
- Point and hold the camera steady in the direction to capture the video. Press the SHUTTER button to start video recording. You will hear one beep as an indication that the recording process has started.
- Press the SHUTTER button a 2<sup>nd</sup> time to stop video recording. You will hear one beep as an indication that the recording has stopped and you will see the front counter digit updated.

***(Note: Make sure to press the SHUTTER button a 2<sup>nd</sup> time to stop video recording, otherwise it will record video indefinitely until the memory capacity is reached, or until you turn the power off.)***

## STC-I840IR

### Viewing Images

The STC-I840IR cam offers the user different options for viewing the images. The external LCD display on the front of the housing will show the number of images in memory.

### Download to PC to View Images


The Stealth Cam STC-I840IR Digital Scouting Camera is a plug and play unit for users of Windows XP, 2000, and ME operating systems, and need not install a camera driver. If your PC operating system is older, then visit [www.stealthcam.net](http://www.stealthcam.net) to download the appropriate camera driver.

***NOTE: Users of Windows 98SE or earlier must download and install the camera driver prior to connecting the USB cable.***

- Make sure the Power switch is in the OFF position before connecting the USB cable to the camera.
- After you connect the USB cable to the computer, **slide the power switch from OFF position to TEST position.** You will see an USB ICON on the upper right hand corner of the LCD screen.
- For a plug and play operating system, your computer will

## STC-I840IR

recognize the camera as mass storage unit and allow you to see the images stored in the camera, or images on the SD card if you are using one.



### **Viewing the image on a handheld LCD TV video monitor, or your home TV equipped with an RCA input jack (cables sold separately)**

For viewing on a handheld LCD TV, attach the appropriate cable to the video OUT jack on the camera. Insert the other end into the video IN jack on the handheld LCD TV monitor.

For viewing on your home TV, attach the appropriate cable to the video OUT jack on the camera. Insert the other end into the RCA video IN jack on the TV. Make **sure to switch to VIDEO IN mode**

## STC-I840IR

### **on your TV. (See your TV owner's manual for directions)**

Turn on the TV monitor and slide the camera power switch to TEST.

- Your camera is preset to NTSC TV out system by default.
- Press the OK button on the camera. This will display the last image captured.
- Using the LEFT/RIGHT buttons to select the image you wish to view. Image number and total number of images in memory will display on the center bottom of the screen.
- Once you have selected the image you wish to view, press the UP button. This will magnify the image on the screen.
- Using LEFT/RIGHT/UP/DOWN buttons, you can move the image to display different areas of the image.
- To return to the image selection view from the magnified image screen, press the OK button.

## STC-I840IR

### Viewing AVI Clip on hand held TV or home TV monitor

- Follow the cable attaching instruction listed in hand held TV or home TV monitor described in previous section.
- Press the OK button on the camera. This will display the last image captured.
- Press LEFT / RIGHT button to scroll through the images in memory. An AVI motion clip image will have a movie icon showing on the upper left hand corner of the image.
- Press SHUTTER button to play back the AVI motion clip.
- To return to image selection view, press LEFT / RIGHT button at the end of the AVI clip.

**NOTE:** Depend on the type of TV that you are using, you may not be able to see the date/time stamp shown on the bottom of the picture. Rest assures it is there.

## Deleting Images


At any time while viewing images on a Handheld TV or home TV monitor, you may delete images one at a time or all at once.

- While viewing images in normal view, press MENU to enter the SETTING MODE.
- By default, your viewing monitor will display DEL 1. Use the LEFT/RIGHT button to choose the desired function to delete one picture at a time, DEL 1, or delete all pictures at one time, DEL All.
- Press OK to enter Delete Mode. Press LEFT/RIGHT button to choose either YES or NO to proceed with this function.
- Press OK again to confirm deleting image. After deleting image, camera will return to picture viewing mode.
- At any given time you may press MENU button to exit from the delete images mode.

## Formatting Memory Card

To erase images stored in memory, or to format an SD card:


Slide the power switch to TEST position. You will hear two short consecutive beeps followed by a third beep.

- Press Menu button once.
- Press the Down button once.
- The Trash icon will flash.  Press OK to confirm you want to format the memory.
- The word “no” and the Trash icon will be flashing. If at this time you decide not to proceed with the formatting of the memory, press OK to exit. Otherwise press the Left button once. The word “YES” and the Trash icon will flash. Press OK to confirm you want to proceed with formatting the memory.

## Using External Power

The Stealth Cam STC-I840IR is designed to be used with an optional external 12V lead acid battery kit (STC-12VBB- sold separately). It is recommended for use in cold weather environments, or situations where your camera would be unattended for long periods of time.

- ❖ *Make sure to install cables in correct polarity (+/-) with a lead acid battery. Incorrect voltage or polarity (+/-) will result in damage to the camera.*



## **Technical Specifications**

### **System Requirements and Compatibility**

- Windows Me/2000/XP/Vista.
- Pentium 4, 2GHz or above
- 1GB RAM (2GB recommended)
- 32 bits color, resolution 800 x 600 or above. Built in 128MB
- 2GB free hard disc space
- An available USB 1.1 port (USB 2.0 recommended)
- Direct X 9.0 or above – Should come with your operating system already.
- Optional: Windows compatible sound card and speaker.

***If you have any questions regarding your PC specifications, please call your PC manufacturer.***

## STC-I840IR

### Camera Features

- Built in 1.8" B&W LCD display
- Built in 32MB flash memory for image & video storage
- External memory support: SD memory card up to 2GB
- Resolution Options: High, Low, Base
- Quality Options: Low, Normal, Fine
- 4 Capturing Options:
  - ❖ Manual : Single or Video (AVI)
  - ❖ PIR activation : 1~9 Burst mode or adjustable Video clip
- Video resolution: VGA 640 x 480
- Auto white balance and auto exposure
- 36 IR Emitter Range: 40 feet
- Military Time Format for date and time stamping
- Time/Date/Moon Phase/Temperature Stamping on all images and video clips.
- 4 digits LCD Image counter; Battery low indicator
- Green Test LED indicator for area detection

## STC-I840IR

- TV out support for NTSC and PAL system
- High precision 2P+2G glass lens
- Effective viewing Angle: 54 deg; Focus: 15 feet ~ Infinity
- PIR detection angle 45 degrees
- Adjustable PIR detection range up to 30ft
- Low power consumption:  
Standby current: < 3 mA; Capture current < 100mA
- Interface type: USB
- Power: C size alkaline batteries x 8 (not included)
- Image format: Standard JPEG & Motion JPEG (AVI)

## General Information

### Storing conditions

- Store in cool and dry location when it's not in use.
- Operating Environment: 14 to 104 deg F (-10 to 40 deg C).  
20-85% relative humidity, non-condensing

### Special Care Instructions

- The camera is designed to be weather resistant. Never attempt to immerse the unit to water or any other liquid. This will damage the unit and void the warranty.
- Use a soft lens cloth for cleaning the lens. Avoid touching the lens with your fingers.
- Remove dirt or stains with a soft cloth dampened with water or neutral detergent. Keep the camera in a dry and cool dust-free environment or container when NOT in use.
- Take the batteries out when the camera will not be used for an extended period of time.
- Avoid dropping the camera on to hard surfaces. Do not disassemble the camera.
- Do not mix new and old batteries.

## STC-I840IR

- Always use fresh batteries.
- For longer battery performance, use the Stealthcam lead acid 12V battery pack (optional).
- Do not open the camera in an attempt to do an unauthorized service. This may cause serious damage to the unit and will void the warranty.






































This camera is a precision electronic device. Do not attempt to service this camera yourself, as opening or removing covers, may expose you to dangerous voltage points or other risks.

May be protected by one or more U.S. Patent numbers:

6,735,387 / 6,768,868 / 6,834,162 / 7,149,422 / 7,308,196 / 7,593,632

STC-I840IR

## Moon Phase Symbol Chart

Symbol	Lunation from to		Actual phase				
	1	5					
	6	10					
	11	14					
	15	16					
	17	20					
	21	25					
	26	29 or 30					

## STC-I840IR

### ***Caution:***

Modification not approved by the party responsible for compliance could void user's authority to operate the equipment

### ***FCC Compliance***

This equipment has been tested and found to comply with the limits for Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio or television receptions, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measure:

- ❖ Reorient or relocate the receiving antenna.
- ❖ Increase the separation between the equipment and the receiver.
- ❖ Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

**Consult the dealer or an experienced radio/TV technician for help.**

Product specifications are subject to change. Stealthcam is not responsible for any photographic or typographical errors.